

# Liveness Detection Using An Intensity Based Approach in Fingerprint Scanners

Bozhao Tan  
Dr. Stephanie Schuckers

Clarkson University  
Sept. 20 2005

# Outline

- ◆ Background for liveness detection
- ◆ Intensity-based approach
- ◆ Results of three different scanners
- ◆ Conclusion and future work

# Background

- ◆ **Fingerprint scanners are susceptible to spoof attack by “fake” fingerprints**
  - ◆ Lifted latent fingerprints
  - ◆ Artificial fingers: gummy fingers, casts made from gelatin, play-doh etc
  - ◆ Worst case: dismembered fingers
- ◆ **Liveness detection**
  - ◆ An anti-spoofing method
  - ◆ Improves reliability and security of biometric system
- ◆ **Detection of perspiration pattern**
  - ◆ Time series images
  - ◆ Developed by our lab
- ◆ **Previous algorithms**
  - ◆ Ridge signal algorithm
  - ◆ Wavelet based algorithm
- ◆ **Motivation:** improve accuracy and speed

# Human Visual Difference for Live and Non-Live Fingerprint Images



0 second



5<sup>th</sup> second

Live Image


Spoof Image

Cadaver Image


# Features Extraction Based on Perspiration Pattern

- ◆ The basis of *static* features: live fingerprints looks “patchy” due to the perspiration pattern
- ◆ The basis of *dynamic* features: live fingers demonstrate a distinctive changing moisture pattern between 0 second and 5<sup>th</sup> second images


# Ridge Signal Algorithm



Live Fingerprint Signal




Spoof



Cadaver

- ◆ Capture time-series images over 5 seconds
- ◆ Map a 2-D fingerprint image to a 1-D signal representing the grey levels along the ridges
- ◆ 7 static and dynamic features are extracted
- ◆ Perform classification between live and non-live using BPNN

# Wavelet Based Algorithm



- ◆ Perform wavelet transform on 0 and 5<sup>th</sup> second images
- ◆ Extract low frequency content using multiresolution analysis
- ◆ Extract high frequency content using wavelet packet analysis
- ◆ Perform classification using energy content of changing coefficients



# Intensity Based Approach

- ◆ Motivation: improve speed with reasonable accuracy
- ◆ Approach: quantify grey level differences between live and non-live fingerprint images using histogram distribution statistics
- ◆ Advantages: simple, efficient and saving time





# Intensity Based Approach -Examples

Live





Play-Doh





# Intensity based Approach -Examples (Cont.)

Gelatin



Cadaver



# Intensity Based Approach -Steps

- ◆ Pre-process to remove noise and normalize
- ◆ Adaptively select interesting area
- ◆ Perform histogram distribution analysis for time-series images
- ◆ Extract static and dynamic features
- ◆ Generate and determine classification tree using training and validation dataset
- ◆ Test with final test dataset

# Classification Tree

- ◆ Derives a sequence of if-then-else rules in order to assign a class label to the input data
- ◆ A data mining technique
- ◆ Commercial tools: CART, See 5, SPSS etc
- ◆ Free tool : Classification Tree in Excel

*<http://www.geocities.com/adotsaha/CTree/CtreeinExcel.html>*

# Some Hints

- ◆ Different scanners have different histogram distributions
- ◆ Select appropriate features to different scanners
- ◆ Adaptively select area to avoid scars
- ◆ Some live fingerprints are very wet and change very little
- ◆ Some cadaver fingerprints change like a live finger, but their grey levels are different than live fingers
- ◆ Classification tree takes these situations into consideration

# Fingerprint Sensors and Dataset

- ◆ **Fingerprint Sensors**



- ◆ Capacitive DC: Precise Biometrics 100SC
- ◆ Optical: Secugen FDU01
- ◆ Electro-optical: Ethentica USB2500

- ◆ **Dataset**



- ◆ Live: 58
- ◆ Spoof: 50(Play-doh and gelatin)
- ◆ Cadaver: 28
- ◆ Training (4/9), validation(2/9) and test(1/3) set

# Precise: Features Extraction

Live



Spoof




$$H1\_before = A = \sum_{i=1}^{100} h1(i)$$

$$\text{Ratio} = \frac{C}{B} = \frac{\sum_{i=246}^{256} h2(i)}{(\sum_{i=1}^{245} h2(i) + 0.1)}$$


$$\text{Dif\_256} = D = \sum_{i=246}^{256} |h1(i) - h2(i)|$$

# Precise: Features Extraction




Cadaver Spoof Live

Ratio



Cadaver Spoof Live

H1\_before




Cadaver Spoof Live

Dif\_256



# Precise: Classification Tree and Results



## Training Data

| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 19              | 1     | 20 |
| spoof      |                 | 30    | 30 |
|            | 19              | 31    | 50 |

## Validation Data



| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 16              | 2     | 18 |
| spoof      | 1               | 20    | 21 |
|            | 17              | 22    | 39 |

## Test Data



| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 20              |       | 20 |
| spoof      |                 | 32    | 32 |
|            | 20              | 32    | 52 |

# Secugen: Features Extraction

Live



Spoof




$$\text{Ratio} = \frac{B}{A} = \frac{\sum_{i=150}^{254} h1(i)}{(\sum_{i=1}^{149} h1(i) + 0.1)}$$

$$H1\_behind = B = \sum_{i=150}^{254} h1(i)$$


$$Dif\_256=C=\sum_{i=255}^{256} |h1(i) - h2(i)|$$

# Secugen: Features Comparison




Cadaver Spoof Live

Ratio



Cadaver Spoof Live


H1\_behind



Cadaver Spoof Live

Dif\_256

# Secugen: Classification Tree and Results



## Training Data

| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 24              |       | 24 |
| spoof      | 2               | 34    | 36 |
|            | 26              | 34    | 60 |

## Validation Data



| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 13              | 1     | 14 |
| spoof      | 1               | 16    | 17 |
|            | 14              | 17    | 31 |

## Test Data



| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 18              | 2     | 20 |
| spoof      | 2               | 23    | 25 |
|            | 20              | 25    | 45 |

# Ethentica: Features Extraction

Live




Spoof



$$\text{Dev} = \text{std}(h2(i)) \quad P_{\text{before}} = \frac{A1}{A2} = \frac{\sum_{i=1}^{80} h1(i)}{\sum_{i=1}^{80} h2(i)}$$


$$\text{Dif}_0 = B = \sum_{i=1}^{10} |h1(i) - h2(i)| \quad \text{Dif}_{256} = C = \sum_{i=200}^{250} |h1(i) - h2(i)|$$

# Ethentica: Features Comparison




Cadaver Spoof Live

Dev




Cadaver Spoof Live

Dif\_256



Cadaver Spoof Live


P\_before



Cadaver Spoof Live

Dif\_0

# Ethentica: Classification Tree and Results



## Training Data

| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 29              | 1     | 30 |
| spoof      | 2               | 32    | 34 |
|            | 31              | 33    | 64 |



## Validation Data

| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 7               |       | 7  |
| spoof      | 1               | 12    | 13 |
|            | 8               | 12    | 20 |

## Test Data

| True Class | Predicted Class |       |    |
|------------|-----------------|-------|----|
|            | live            | spoof |    |
| live       | 17              | 1     | 18 |
| spoof      | 4               | 21    | 25 |
|            | 21              | 22    | 43 |

# Outcome Summary



- ◆ Success ratio: 84%~100%
- ◆ Grey level differences are specific to the type of spoof images we collected



# Conclusion and Future Work

- ◆ Intensity based approach
  - ◆ Static and dynamic features are extracted to quantify gray level differences
- ◆ Classification tree
- ◆ Simple, efficient and saving time
- ◆ Purely software based
- ◆ Anti-spoofing protection for fingerprint scanners
- ◆ Future work
  - ◆ Consider other methods to defeat liveness algorithm
  - ◆ Study existence of perspiration pattern over larger number of subjects

Three balloons (green, light blue, and purple) with yellow streamers and triangular flags are positioned on the left side of the slide.

Thank You  
Questions ?